



## Installation | Score

### UPON PRODUCT DELIVERY

1. Verify packing slip matches with product and order and inspect delivered product thoroughly.
2. Store product and adhesive in clean, dry environment with temperatures between 55°F and 80°F and humidity between 35 percent and 55 percent, in a room with working HVAC.
3. The material must be acclimated to the environment where it will be laid for at least 72 hours before installation.
4. Read product and subfloor preparation instructions carefully and completely before beginning any installations.

### PREPARATION

#### **PRODUCT**

Score wood planking should be protected from excessive moisture and other damage prior to application, during application and while curing.

#### **SUBFLOOR SURFACE**

The subfloor general conditions should be as follows:

- Must be dry all year
- Must be free of wax, oil, grease, sealer, curing compound, paint, varnish, old adhesive, or other contaminants. All contaminants must be removed by mechanical abatement since chemical abatement will lead to additional contaminants.
- Be reasonably flat and free of holes or variances of more than 3/16 inches in 10 feet
- Must be properly prepared to be a satisfactory bonding surface for adhesion of subfloor to Score
- Must be firm, structurally sound, dry, clean, smooth, and level

#### **INSTRUCTIONS FOR PREPARING SUBFLOOR OF FLOATING SYSTEM**

1. Cover concrete with poly sealing and lapping joints a minimum of 6in.
2. Install lower layer of subfloor perpendicular to finished Score planking, spacing all edges 0.25in and stagger joints 4.' Provide 2in expansion voids at perimeter and at all vertical obstructions. The underside of first layer shall have resilient pads attached 12in on center (32 per sheet) and 6in from edges on all sides. Install solid blocking at doorways, under bleachers in the stacked

position, and below portable goals.

3. The second layer of subfloor shall be laid at a 45 degree angle over the first layer, spacing all edges 0.25in and stagger joints 4.' Provide 2in expansion voids at perimeter and at all vertical obstructions. Attach second layer of subfloor with fasteners 12in on center.

### INSTALLATION PROCEDURES

#### **INSTRUCTIONS FOR INSTALLING MAPLE FLOORING**

1. Install maple flooring by power nailing or stapling approximately 12in on center with end joints properly driven up. 2in flooring fasteners should be used.
2. If required, size joints between flooring strips to allow for intermediate expansion in accordance with local humidity conditions.
3. Provide 2in expansion voids at perimeter and at all vertical obstructions.

#### **INSTRUCTIONS FOR APPLYING FINISH AND SEALANT**

1. Machine-sand with coarse, medium, and fine paper to a smooth, even and uniform surface.
2. Remove sanding dust from entire surface by tack or vacuum.
3. Inspect entire area of floor to ensure that surface is acceptable for finishing, clean and completely free of sanding dust.
4. Apply two (2) coats of approved seal and two (2) coats of approved finish per manufacturer instructions.
5. Buff and clean floor between coats.
6. Game Lines: Apply game lines as indicated on drawings, between seal and first coat of finish.