



Installation | **Attack**

UPON PRODUCT DELIVERY

1. Verify packing slip matches with product and order and inspect delivered product thoroughly.
2. Store product and adhesive in clean, dry environment with temperatures between 65°F and 95°F and humidity between 10 percent and 65 percent.
3. The material must be acclimated to the environment where it will be laid for at least 48 hours before installation.
4. Read product and subfloor preparation instructions carefully and completely before beginning any installations.

PREPARATION

PRODUCT

Turf rolls should be protected from excessive moisture and other damage prior to application, during application, and while curing.

SUBFLOOR SURFACE

Each subfloor shall be inspected to determine the special care required to make it a suitable foundation for carpet. All cracks 0.375in (3 mm) wide or protrusions over 1/32in (0.8 mm) should be filled or leveled.

CONCRETE

Concrete shall be cured, clean and dry. If the turf is to be installed using an adhesive, the concrete shall be free of paint, dirt, grease, oil, curing or parting agents, and other contaminants (including sealers) that may interfere with the bonding of the adhesive. Whenever a powdery or porous surface is encountered, a primer compatible with the adhesive shall be used to provide a suitable surface for the glued installation. Patching of cracks and depressions shall be made with appropriate and compatible latex or polymer fortified patching compound. Do not exceed manufacturer recommendations for patch thickness. Large patched areas must be primed.

NOTE

Wood is a suitable subfloor for Attack as long as any finish already present has been sanded to ensure optimal adhesion.

INSTALLATION PROCEDURES

IMPORTANT NOTES

Do not forcefully move turf when folding/unfolding, and be careful to keep carpet square to the centerline and adjoining turf.

INSTRUCTIONS FOR INSTALLING TURF ROLLS

Trimming Selvage:

Trim edges and seams by cutting face down using straight edge and carpet knife. Use a chalk line to mark straight line for cut reference. Use straight edge to prevent jagged edges. For all cut edges of the turf, be sure to use seam sealer (follow package instruction). This is required and prevents any unraveling.

UNDERLAYMENT INSTALLATION - IF INSTALLING ATTACK TURF WITH PLAETECH BACKING

1. Lay rolls on the floor and allow to relax into position overnight or for a minimum of 12 hours.
2. Lay out all rolls that will be installed during that day.
3. Starting at the wall, roll back half the roll width.
4. Apply adhesive to substrate, half of the roll width, with the recommended trowel size on the glue pail.
5. Lay flooring into wet adhesive.
6. Immediately roll the floor with 75lb - 100lb roller to eliminate air traps (overlap each pass of the roller by 50 percent).
7. Fold back the second half of the roll and repeat steps 5-7.
8. Repeat steps 3-8 with all other rolls.

NOTE

Let cure overnight before gluing Attack top layer.

OUTDOOR INSTALLATION NOTES

1. Adding turf to concrete will not change the draining pattern of the concrete.
2. Slope grade should be no less than 0.5 percent and no greater than 0.75 percent.
3. Drainage may occur from center out or from one side of the space to the other side.
4. If an existing drain is present, a hole must be cut into the turf so the drain is exposed.